


Galaxy DX Radios DX2517

Documentation Project

CBTricks.com

ROTARY SW P.C.B. EPT024830Z

[Trace Layout](#)



Resistors

Ref#	Description	MFR. Part No.
R312	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R313	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R314	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R315	C/F/R P-TYPE 470 OHM 1/16W P	RCP164714Z
R316	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R317	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R318	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z

R319	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R320	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R321	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R322	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R323	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z
R324	C/F/R P-TYPE 1.5K OHM 1/16W P	RCP161524Z

Jumpers

Ref#	Description	MFR. Part No.
J301	JUMPER WIRE 7x5x7	WX01070705
J302	JUMPER WIRE 7x10x7	WX01070710
J304	JUMPER WIRE 7x5x7	WX01070705
J306	JUMPER WIRE 7x8x7	WX01070708
D311	JUMPER WIRE 7x7x7	WX01070707
D312	JUMPER WIRE 7x7x7	WX01070707
D313	JUMPER WIRE 7x7x7	WX01070707
D314	JUMPER WIRE 7x7x7	WX01070707
D315	JUMPER WIRE 7x7x7	WX01070707
D316	JUMPER WIRE 7x7x7	WX01070707
D320	JUMPER WIRE 7x7x7	WX01070707
D323	JUMPER WIRE 7x7x7	WX01070707
D324	JUMPER WIRE 7x7x7	WX01070707
D325	JUMPER WIRE 7x7x7	WX01070707
D326	JUMPER WIRE 7x7x7	WX01070707

Connectors

Ref#	Description	MFR. Part No.
J307	PCB CONNECTOR/S 10P PH=2	EX07N48209

Copyright © 2002 CBTricks.com

Disclaimer: Although the greatest care has been taken while compiling these documents, we cannot guarantee that the instructions will work on every radio presented.