

Galaxy DX Radios DX2517

Documentation Project

CBTricks.com

Chassis, Miscellaneous & Mechanical Parts

Ref#	Description	MFR. Part No.
	GLASS WINDOW HOLDER	PT0SSB010A
	PLASTIC FOOT	PT0SSB040A
	LEVEL SW COVER	PT0SSB060A
	METER BACK COVER	PT0SSB070A
	SW KNOB BLACK	PT0SSB080B
	ACRY WINDOW	PT0SSB092A
	LED WINDOW DX-2517	PT0SSB110B
	LED WINDOW(B)	PT0SSB120A
	KNOB WASHER	PT3600090A
	MICA INSULATOR TO-3	PA0100010A
	TOP COVER BLACK	MT0SSB010B
	BOTTOM PLATE	MT0SSB021S
	FRONT CHASSIS	MT0SSB035X
BAND	FRONT PANEL DX-2517	MT0SSB042W
	RIGHT SIDE BRACKET	MT0SSB071S
	LEFT SIDE BRACKET	MT0SSB081S
	HANDLE ASSEMBLY BLACK	MT0SSB120B
	HANDLE ASSEMBLY BLACK	MT0SSB130B
	HANDLE BRACKET	MT0SSB141S
	CHANNEL KNOB	MT0SSB150B
	MIC BRACKET	MT0SSB170N
2N3055	HEAT SINK COVER	MT0SSB310X
	DUAL KNOB (A)	MT0SSB320A
	DUAL KNOB (B)	MT0SSB330A
	HEAT SINK C	MM5500100X
	BACK PANEL	MT0SSB272A
	MAIN PCB CHASSIS	MT0SSB296X
B/G	HEAT SINK E	MT0SSB305X
	HEATSINK D	MT0SSB252B
	SHEILD PLATE	MT0SSB430X
	INDICTOR NAME PLATE	MT0SSB101K
	DISPLAY & INDICATOR CHASSIS	MT0SSB111S
	VR KNOB BLACK	MT0SSB161B
	SUPPORTER OF P.T.	MT0SSB360X
	FIXED PLATE	MT0SSB371X
	PUSH BUTTON	MTTURB150A
DFB,	PCB BRACKET	MT3001010S
51ZPCB	PCB BRACKET	MT3001010S
	MIC PLATE GALAXY	BA0112010A
METER	LAMP STOPPER	QT0SSB020A
	EARPHONE COVER	QM5500030A
-90Z PCB	HEXANGULAR SCREW M3x0.5Px17mm	MD0360041X

COUNTER USE	SPONGE 22x15x4tmm	XZZZ90367A
DISPLAY-CONNTER PCB	HEX SPACER (CBS-5A)	GZZZ50182Z
TOP COVER	SHIELD CLOTH (A) 200x10x0.5t	LZZZ60018Z
SW	SHIELD CLOTH (B) 32x15x0.5t	LZZZ60019Z
SPEAKER	SHIELD CLOTH (C) 106x90x0.5t	LZZZ60020Z
FEET	WASHER (FOR FOOT) 25x9x4t	LZZZ60021Z
METER	FOAM 14x14x2	XZZZ90053Z
METER	FOAM 40x8x2	XZZZ90061Z
MOR PCB	FOAM 14x16x20mm	XZZZ90004Z
SWR PCB	FOAM 14x16x20mm	XZZZ90004Z
	INSULATING PLATE 18x13mm	XZZZ90020Z
2166,	INSULATING RING	XZZZ90003Z
2312x2	INSULATING RING	XZZZ90003Z
2166(1)	INSULATING PLATE 10x14x1.55mm	XZZZ90358Z
2312(2)	INSULATING PLATE 10x14x1.55mm	XZZZ90358Z
ANT A(1)	SOLDER PLATE 3.2mm	XZZZ90002Z
2SD797(1)	SOLDER PLATE 3.2mm	XZZZ90002Z
PLATE(1)	SOLDER PLATE 3.2mm	XZZZ90002Z
EARPHONE	WASHER 6x7x10.8t	XZZZ90057Z
2SD797	INSULATING RING (TO-220D)	XZZZ90316Z
BOTTOM COVER	CAUTION LABEL	LZZZ61066Z
	FIBER PLATE	XZZZ90319Z
	CORD BUSHING SR-5R1	GZZZ50168Z
	CLAMP GT-100M	GZZZ50000Z
	FUSE HOLDER FH-004	GZZZ50049Z
SET (POLYLON & GIFT BOX)	PVC BAG 600x410x830x0.07t	UB07604183
SET	PVC BAG 500x190x740x0.07t	UB07501974
I/M	PVC BAG 220x360x0.05tmm	UB052236ZZ
	POLYLON RIGHT LEFT	UPT0SSB01M
	CARTON DX-2517	UCT0SSBA1W
	G/B DX-2517	UGT0SSBA1W
	I/M DX-2517	AT0SSB010W
	SET SCREW M4x0.7Px12	JS114012MQ
HANDLE(4)	SET SCREW M5x0.8Px12	JS035012MB
FRONT PLATE(3)	SET SCREW M3x0.5Px6	JS033006MN
HANDLE (4)	SET SCREW M5x0.8Px12	JS055012MB
TOP COVER(4)	SET SCREW M5x0.8Px12	JS055012MB
PCB CHASSIS (4)	SET SCREW M4x0.7Px8	JS054008MS
EARPHONE(2)	SET SCREW M3x0.5Px8	JS053008MB
	SET SCREW M3x0.5Px10	JS053010MN
IC(3)	SET SCREW M2x0.4Px12	JS052012MN
437(1)	SET SCREW M2x0.4Px12	JS052012MN
HEAT SINK(4)	SET SCREW M3X0.5PX8	JS053008SN
W/SW 4	SET SCREW M3X0.5PX8	JS053008SN
BACK PANEL(9)	SET SCREW T3x8-2	JS053008TB
INDICATOR	SET SCREW T3x8-2	JS053008TB
HEAT SINK(4)	SET SCREW W3.2x8-1	JS053208WB
ANT(3)	SET SCREW T3x8-2	JS053008TH
SPEAKER(4)	SET SCREW T3.5x8-2	JS053508TH
FEET(4)	SET SCREW T3x14-2	JS013014TH
LED(1)	SET SCREW T3x8-2 STEEL 50	JS013008TH
FRONT PLATE(2)	SET SCREW T3x8-2 STEEL 50	JS013008TH
ECHO (2)	SET SCREW T3x8-2 STEEL 50	JS013008TH
BOTTOM(8)	SET SCREW T3x8-2 STEEL 50	JS013008TH

BRACKET(12)	SET SCREW T3x8-2 STEEL 50	JS013008TH
PCB(09)	SET SCREW T3x8-2 STEEL 50	JS013008TH
DISPLY BRACKET(6)	SET SCREW T3x8-2 STEEL 50	JS013008TH
SPARE PARTS(3)	SET SCREW T3x8-2 STEEL 50	JS013008TH
BACK COVER (9)	SET SCREW T3x8-2 STEEL 50	JS013008TH
RECIFITER(1)	SET SCREW M3x0.5Px18	JS033018MN
IC TA7222(1)	SET SCREW M3x0.5Px8	JS013008MV
SW(2) W/S/W 2	SET SCREW M3X0.5PX6	JS013006SN
MAIN PCBx5	SCREW T3x6-2	JS053006TH
LEVER SWx5	SCREW T3x6-2	JS053006TH
MIC SOLDER PLATEx1	SCREW T3x6-2	JS053006TH
ECHO PCB(2)	SET SCREW M3x0.5Px6	JS053006MN
	M4X0.7P LOCK NUT	JN284007ZN
2SD797	SET SCREW M3x0.5Px12	JS053012MN
TR41	SET SCREW M2x0.4Px6	JS052006MN
EAR PHONE	INSULATE WASHER 6QX11.5X0.5T	JW306011EY
	SPRING WASHER 4x6x1t	JW344006GN
SET (TOP COVER) (4)	WASHER 5.3x12x0.8t (BLACK)	JW305312FB
HANDLE (4)	WASHER 5.3x12x0.8t (BLACK)	JW305312FB
PCB(5)	IN-TOOTH WASHER 3Q	JW323006DN
	NUT WITH WASHER M3x3.5t	JN263035ZS
FEET	WASHER 4Qx9x0.8	JW304009FS
	NUT M3x2.4t	JN243024ZS
	BOX FOR SPARE PART 90x50x120	UWT0SSB01A
SPARE PARTS	PVC BAG 100x150x0.05tmm	UB051015ZZ
	OUT-TOOTH WASHER 5.5x10x0.3tmm	JW315510CN
	IN-TOOTH WASHER 4x8x0.3tmm	JW324008CN
	SET SCREW W5x10-1	JS015010WH
	MIC STOPPER	XZZZ90008Z
	FUSE 125V 5A	EX02N40214

Copyright © 2002, 2003, 2004 CBTricks.com

Disclaimer: Although the greatest care has been taken while compiling these documents, we cannot guarantee that the instructions will work on every radio presented.