


MODE/BAND JUMPERS:
OPT1 SCAN AUTOSTART, cut to disable autostart
OPT2 RUSSIA ONLY, place to set RU only mode
OPT3 ALL, cut to enable selection of all bands
OPT5 HIGH POWER, cut to enable 10W mode
OPT9 Disables RF power, if in place
OPT10 TEST MODE, Factory use only
OPT11, OPT12 , Caution, use only one of these:
- OPT11 in place / USB power supply directly from battery
- OPT12 in place/ USB power supply after radios ON/OFF switch.



when placed

before ON/OFF switch
OFF switch

