

Exploded drawing for Base Camp 446 (Front cover assy portions) Dec 9, 2008

No.	Dwg. No.	Part Name	Descriptions	Qty	Remark
1	XT511-004	Power Volume knob	ABS	1	
2	XT511-008	Tone Control Knob	ABS	1	
3		Dual Shaft Volume switch	F-09225S B10K/B50K L113x5 L21.8FCx6(D)	1	
4		Sub PCB	For Power/Volume/Tone control switch	1	
5	MIC	MIC		1	
6	XT511-011	Slide Knob	ABS	3	
7	XT511-005	Tuning Knob	ABS	1	
8		Slide Switch (2 positions)	SS-12F18-G4	2	
9		Slide Switch (4 positions)	SS-24H01-G4	1	
10		Tuning Switch	Self Return Switch : E-C11ESRA01E	1	
11		Dynamo Motor and Gear Assay		1	
12		AM Bar Antenna assay		1	
13	BC446-001	Front cover (BC446)	ABS	1	
14	FEL-T-052	Sepaker Felt	Speaker Felt 0.1t Black, Ø52.0 mm	1	
15		Speaker	Speaker Ø57, 8 ohm 2 watt, YD57B-199F8	1	
16	XT511-023	Speaker Bracket (XT511)	Galvanized Steel 1.2t	2	
17		Screw	PH T2.6 x 8 Black	6	
18	XT511-006	LCD Window (XT511)	Acryl	1	
19	XT511-025	LCD Bracket	SPTE 0.5t	1	
20	XT511-LCD	LCD (XT511)		1	
21	XT511-Zebra	Zebra (XT511)		1	
22	XT511-007	Back Light Lens (XT511)	Acryl	1	
23	XT511-053	Reflective Sheet (XT511)	PE 0.1t White	1	
24		Main PCB		1	
25		Sub PCB	For light LEDs	1	
26	XT511-009	Window for light (XT511)	Acryl	1	
27	XT511-010	Reflective Frame for light (XT511)	ABS, Cr-plate	1	
28	LEDs	LED for light		3	
29		Metal Dome		5	
30		Tape for Metal Dome		5	
31	XT511-012	Function Buttons (XT511)	Silicone rubber 60°	1	
32		DC Power Jack		1	
33		Header Jack		1	
34		USB Jack		1	
35		Sub PCB	For function buttons	1	
36		Dynamo handle assy		1	
37	XT511-054	Cushion		1	
38		Grease	Silicone Grease or Bearing Grease	Some	
39		Cable Tie		1	
40		FM Antenna		1	

