


## MODE MO'THODE

| BAND \ PIN NO |           | 9 | 10 |
|---------------|-----------|---|----|
| MODE 1        | 40 AM/FM  | L | L  |
| MODE 2        | 400 AM/FM | H | L  |

## CHANNEL EXPANSION

L: SHORT      H: OPEN

1. Switch Power OFF
2. Disconnect Power lead from the Power Supply
3. Change (modification) from cpu mode as per above table.
4. Connect Power lead to the power supply and power switch turn ON.
5. Now the unit become CB 400 channel, and CH9/19 button become band switch.
6. Press CH9/19 (band switch) channel display changed to band display and again repeat this switch press, will be display A, B, C, D, E, F, G, H, I, J.



9 10  
→ Remove Soldering