


MODIF EXPORT SUPERSTAR 3900 EFT



MOVE THE STRAP **J28** OF A NOTCH IN THE SENSE OF THE ARROW

MOVE THE CONNECTOR **J4** ON THE CONNECTOR **J2**

DELETE THE WELDED RESISTANCE ON **IC5** (weld side)

VR 13 MODULATION SSB

VR 17 POWER SSB

VR 16 MODULATION AM

VR 14 POWER AM/FM

VR 18 ADJUSTMENT MINIMUM POWER

VR 9 VU-METER TX

